

Callies Finish Ground Cam List - Small Block Chevy

Callies Part #	Solid or Hyd	Duration @ .050		Advertised Duration (@ .020)		Cam Lift		Valve Lift w/1.5 Rocker		LSA + Advance	Lobe Ctr.		Lift @ TDC		Application	Specific Remarks	
		Intake	Exhaust	Intake	Exhaust	Intake	Exhaust	Intake	Exhaust		Intake	Exhaust	Intake	Exhaust			
100 - SBC Std. Brng.																	
100-001	SR	276	288	307	319	0.470	0.470	0.705	0.705	115 + 1	114	116	0.129	0.145	Nitrous	LS Firing Order	
103 - SBC LW Sprint															<i>Lightweight Sprint / Standard Spacing / 55mm Bearing</i>		
103-003	SR	261	264	292	300	0.430	0.434	0.645	0.651	107 + 0	107	107	0.148	0.165	360 Sprint - Narrow lobes	LS Firing Order	
103-002	SR	261	265	294	304	0.447	0.450	0.671	0.675	107 + 0	107	107	0.144	0.164	360 Sprint - Narrow lobes	LS Firing Order	
103-004	SR	262	265	305	315	0.475	0.478	0.713	0.717	107 + 0	107	107	0.150	0.173	360 Sprint - Narrow lobes	LS Firing Order	
103-001	SR	262	268	294	304	0.430	0.430	0.645	0.645	107 + 0	107	107	0.144	0.164	360 Sprint - Narrow lobes	LS Firing Order	
103-005	SR	268	270	305	315	0.480	0.491	0.720	0.737	105 + 0	105	105	0.150	0.173	360 Sprint - Narrow lobes	LS Firing Order	
104 - SBC LW Sprint															<i>Lightweight Sprint / Styers Spacing / 55mm Bearing</i>		
104-001	SR	268	272	297	302	0.480	0.446	0.720	0.669	111.5 + 3.5	108	115	0.145	0.121	410 Sprint - Narrow lobes	LS Firing Order	
107 - 4.5 SB 50mm															<i>4.500 Spread Bore SBC 50mm Bearing</i>		
107-001	SR	265	277	298	310	0.433	0.438	0.650	0.657	109 + 0	109	109	0.125	0.149		Std. Firing Order	
107 - 4.5 SB 55mm															<i>4.500 Spread Bore SBC 55mm Bearing</i>		
107-005	SR	264	272	292	300	0.484	0.491	0.726	0.737	106.5 + 0	106.5	106.5	0.148	0.165	Dirt Late Model	LS Firing Order	
107-006	SR	266	276	294	304	0.484	0.491	0.726	0.737	108 + 0	108	108	0.144	0.164	Dirt Late Model	LS Firing Order	
107-009	SR	276	286	305	315	0.454	0.454	0.681	0.681	110 + 0	110	110	0.150	0.173		LS Firing Order	